


DMMD Umrüstung von Hallgasgriff auf Potentiometer



Der verwendete Gasgriff-Sensor muss in der Software des DMMD konfiguriert werden. Bei einem DMMD für Hallgasgriff ist eine nachträgliche Umrüstung von **Hallgasgriff auf ein 5 kOhm Potentiometer-Gasgriff** mit zwei zusätzlichen Widerständen gemäß der dargestellten Schaltung ohne Neukonfiguration des DMMD möglich.



Bei einem DMMD für Potentiometer-Gasgriff ist für eine nachträgliche Umrüstung von **Potentiometer-Gasgriff auf Hallgasgriff** eine Neukonfiguration des DMMD erforderlich.

picoamps GmbH

Ingelsberger Weg 50
D-85604 Zorneding
www.picoamps.de

phone: +49 (0)8106 99 79 688
fax: +49 (0)8106 99 79 689
e-mail: info@picoamps.de




DMMD Conversion from Hall to Potentiometer throttle



The applied throttle type has to be configured within the DMMD software.

Using a DMMD configured for Hall type throttle, a conversion from **Hall type to 5kOHM Potentiometer type throttle** is possible by simply adding two resistors to the throttle circuitry as shown in the picture below.



Using a DMMD configured for Potentiometer type throttle, the configuration of the DMMD software has to be changed for a conversion from **Potentiometer to Hall type throttle**.

picoamps GmbH

Ingelsberger Weg 50
D-85604 Zorneding
www.picoamps.de

phone: +49 (0)8106 99 79 688
fax: +49 (0)8106 99 79 689
e-mail: info@picoamps.de

